




E. CURVAS DE PAR MOTOR Y POTENCIA  
E. COURBES DE COUPLE ET DE PUISSANCE  
E. TORQUE AND POWER CURVES

Fig. 7



20 —

FROM 198/199 OWNERS HANDBOOK



FROM WORKSHOP SERVICE MANUAL FOR MODELS PRIOR TO 198/199