PGM-FI Fuel Injection



① Pick Up (Crank position sensor)
② Engine coolant temp. sensor (ECT)
③ Intake pressure sensor (MAP)
④ Intake air temp. sensor (IAT)
⑤ Throttle position sensor (TP)
⑥ ECM (Electronic Control Module)
⑦ Idle adjusting screw
⑧ Throttle body
⑨ Bank Angle Sensor (BAS)
⑩ Fuel pump
⑪ Fuel filter
⑫ Fuel tank
⑬ Air filter
⑭ Injector
⑮ Pressure regulator
⑯ Return hose
⑰ Fuel pressure hose